

Handguard Mounting Tips for Arctic Cat ZR snowmobile chassis

Check your handguard model:

- For **Star Series Handguards** use snowmobile mount kit #34250.
- For **Sentinel Handguards** (pictured) use snowmobile mount kit #34450.

Use these instructions along with the instructions along with the instructions provided in mount kit.

Right side bracket:

Loosen your throttle assembly and slide to the left. You may need to get extra grip heater wire by removing the handle bar cover and sliding the heated grip wires through the throttle block. Be careful not to damage the wires while doing this. When installing the mounting bracket, make sure the wires are not pinched. Mount the throttle side bracket between the grip and the throttle assembly as shown in the photo.



Left side bracket:

Loosen your brake assembly and slide to the right. If you need extra grip heater wire remove handle bar cover and slide the heated grip wires through the brake mount. Be careful not to damage the wires while doing this. Make sure the wires are not pinched by the mounting bracket. Mount handguard bracket between brake and grip and over the top of the lever as shown in the photo.



Handguard mounting:

The handguard can be mounted to the bracket in multiple positions from left to right using the spacers provided. This allows you to get the handguard in just the right spot to provide the best protection. A good location is when the outside end of the handguard matches up with the outside end of the grip - as shown in the photo. Follow the instructions provided with your mount kit to mount the handguard.

Adjust guard and brake lever to your personal preference. Make sure all fasteners are tightened.

