

PowerMadd Sentinel Handguard Mounting Can Am Outlander

NOTE: Use these instructions along with the instructions provided with the 34452 Sentinel handguard mount kit.

If installed remove the OEM handguards.

Left Side:

Loosen brake perch assembly and slide to the right just enough to make room for the mounting bracket. Mount bracket over the top of the lever as shown in the photo. Adjust height and width of the handguard to your preference using the instructions provided in the 34452 mount kit. Tighten all fasteners.



Throttle Side:

Mount bracket just to the left of the throttle block as shown in photo. Adjust height and width of the handguard to your preference using the instructions provided in the 34452 mount kit. Tighten all fasteners.



If installing the PowerMadd Hand Wrap (34253) use the instructions included with the hand wrap for information on how to install. Reference above photos for mounting location.

If your ATV came with Can Am's full wrap hand guards you can use the internal handle bar cones. See photo

