

PowerMadd Sentinel Handguard Mounting
2017 Yamaha FZ10
2018-2019 Yamaha MT-10

NOTE: Use these instructions along with the instructions provided with the 34452 Sentinel handguard mount kit.

Clutch Side:

Loosen clutch perch assembly and slide to the right just enough to make room for the mounting bracket. Mount bracket over the top of the lever as shown in the photo. Adjust height and width of the handguard to your preference using the instructions provided in the 34452 mount kit. Tighten all fasteners.



Throttle Side:

Loosen front brake perch and slide left (towards center of motorcycle) just enough to make room for the mounting bracket. Mount bracket over the brake lever, between the brake perch and throttle assembly as shown in the photo. Adjust height and width of the handguard to your preference using the instructions provided in the 34452 mount kit. Tighten all fasteners.



Sentinel Street LED light kit instructions
2017 FZ10
2018-2019 MT-10
34491

NOTE: Use these instructions along with the instructions provided in the Sentinel Street LED light kit (34491).

NOTE: Due to the low locations of the turn signals. Two additional 12” sections of 22 gauge wire are required to tap into the existing turn signal wires.

Attach 12” sections of 22 gauge wire to the yellow and white wire wires coming out of the LED module. Seal your connections with electrical tape.

Connect all four of the supplied spade terminals to the four wires on the LED module.

Remove the front cover and upper cover along with the meter cover to gain access to the keyed power source. The blue wire is the positive lead and the black wire is ground. T-tap into these wires. See photo.

In this area you should have space to place your LED Module. See photo

Remove the Left air scoop to gain access to the left turn signal wire (brown). T-tap into the brown turn signal wire. See photo

Route the yellow (left turn signal) wire from the LED module to the brown wire. The wire can be hidden in the panels that run from the headlight into the air scoop. Connect the spade terminal into the brown wire with the T-tap. Carefully secure all wires and reassemble the air scoop.

Repeat these steps for the right side. White wire is the right turn signal wire. See photo.

Using the instructions provided with the 34491 kit, complete the installation of the Sentinel Street LED light kit.

