

## PowerMadd Sentinel Handguard mounting on KTM EXC and XC models

### 34452 ATV/MX Mount

**NOTE:** Use these instructions along with the instructions provided with the mount kit. If installing the 34253 Handwrap use those instructions after installing the handguards.

#### Clutch side:

Loosen the clutch perch assembly and move to the right (towards center of motorcycle) just enough to make room for the mounting bracket. Mount bracket over the top of the lever, between controls and clutch perch as shown in photo. Adjust height and width of the handguard to your preference using the instructions included in the 34452 mounting kit. Tighten all fasteners.



#### Throttle side:

Mount bracket underneath the brake lever just to the left of the brake perch as shown in the photo. Adjust height and width of the handguard to your preference using the instructions included in the 34452 mounting kit. Tighten all fasteners.

