

# Handguard Mounting Tips

## For Polaris Edge Snowmobiles

### Check your handguard model:

- For **Star Series Handguards** use snowmobile mount kit #34250.
- For **Sentinel Handguards** (pictured) use snowmobile mount kit #34450.

Use these instructions along with the instructions along with the instructions provided in mount kit.

We suggest using a 2" non-pivot riser block to improve rider comfort and aid in handguard clearance with your windshield.

If your sled has the full rubber handle bar cover (photo 1) you will need to either:

1. Remove the cover and cut slots in both sides for the handguard mounting brackets (see photo 2). Mount guards before cutting.
2. Remove cover and replace with a smaller option such as PowerMadd's Riser Bag part # 73603 (2" riser required) or PowerMadd Fat Bar Pad part # 44261.



Photo 1



Photo 2



Photo 3 -  
Riser Bag



Photo 4 -  
Bar Pad

### Left side bracket:

Mount the handguard mounting bracket just to the right of the brake control pod with the bracket going over the top as shown below.



### Right side bracket:

Mount the handguard bracket just to the left of the throttle block as shown below.



### Handguard mounting:

The handguard can be mounted to the bracket in multiple positions from left to right using the spacers provided. This allows you to get the handguard in just the right spot to provide the best protection. A good location is when the outside end of the handguard matches up with the outside end of the grip - as shown in the photo. Follow the instructions provided with your mount kit to mount the handguard.

Adjust guard and brake lever to your personal preference. Make sure all fasteners are tightened.