

PowerMadd Sentinel Handguard mounting on 2008 to current Ski Doo XP, XS and XM

Using the 34450 Snow Mount or 34452 ATV/MX Mount

Note: Will not work with Ski Doo Ultra High Windshield

Note: If you have a medium injection molded shield with side deflector kit the guards may rub on shield depending on how you have your handle bars adjusted.

* Works great with all Cobra by PowerMadd XP windshields.

* Use these instructions along with the instructions provided in the Mount kit.

Brake side:

Loosen brake perch and move to the right slightly. Mount handguard bracket right next to control pod running the bracket underneath the brake reservoir.

Slide brake perch right next to the handguard bracket.

Mount bracket next to the right mounting tab on the handguard. See photo for reference

Adjust guard and brake lever to your personal preference.



Throttle side:

Mount handguard bracket right next to throttle block and kill button running the bracket underneath (if you are using the ATV/motorcycle mount kit).

Mount bracket next to the left mounting tab on the handguard. See photo.

Adjust guard and throttle lever to your personal preference.

