

## PowerMadd Star Series Handguard mounting on Yamaha Apex and Nytro up to 2008

### 34250 Mount kit

**NOTE:** Use these instructions along with the instructions provided with the mount kit.

#### Brake side:

Loosen the brake perch assembly and move to the right (towards center of snowmobile) just enough to make room for the mounting bracket. Mount bracket over the top of lever and between grip and brake perch as shown in photo. Make sure to have grip heater wire run on the outside of the mounting strap. Adjust height and width of the handguard to your preference using the instructions included in the 34250 mounting kit. Tighten all fasteners. You will also need to adjust the parking brake so it will not hit the handguard mounting bracket when engaged.



#### Throttle side:

Mount bracket just to the left of the throttle block as shown in the photo. Adjust height and width of handguard to your preference using the instructions included in the 34250 mounting kit. Tighten all fasteners.

