

POWERMADD® SR Viper Windshields

Installation Instructions for Part No. 14521, 14530 & 14540

HARDWARE INCLUDED:

Qty	Description
1	Windshield
2	Well Nuts
2	Finishing Cap Washers
2	Black Finishing Caps
2	Machine Screws
1	Template
1	¼" Hole Plug

TOOLS REQUIRED:

Description
Drill
3/8 Drill Bit
Torx T20
Scissors

STEP 1: Start by removing the stock windshield. Remove the screws holding the windshield on.

STEP 2: Once the windshield is removed, cut out the attached template. Use the template to mark where the rear mounting holes will be drilled.

Photo 1

STEP 3: Once the holes have been marked, use a 3/8" drill bit to drill the holes in the location marked in step 2. **Note:** Use caution when drilling as to not drill too deep. *Photo 2*

STEP 4: Insert the two supplied well nuts into the holes you just drilled.

STEP 5: Place the windshield on the instrument pod.

STEP 6: Insert the original torx screws through the two front holes of the windshield. Tighten the screws. **Note:** Be careful not to over tighten.

STEP 7: Next insert and tighten the four original side screws.

STEP 8: Place the supplied finishing cap washers on the supplied machine screws to be used in the rear most mounting holes.

STEP 9: Insert the screws through the windshield into the rear well nuts. Once inserted, tighten the screws.

STEP 10: Install the black finishing caps.

STEP 11: Install the ¼" hole plug in the front most hole in the windshield.

Photo 1



Photo 2



LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

