



EZ-Out Pull Strap™

Instructions for PM81050

The EZ-Out Pull Strap consists of a 6' pull strap with an oversized hook on one end and an ergonomically designed pull handle on the other. Included is a hook-n-look strap to keep the EZ-Out neatly rolled-up.

Hook placement on Snowmobiles:

Place the hook on the snowmobile ski loop with the hook opening facing the inwards (see Fig. 2). This will allow the hook to fall off the ski as the driver accelerates.


Hook placement on ATVs:

Place the hook on the ATV frame / bumper with the hoop opening facing upward.

Using the EZ-Out Pull Strap:

Keep strap taught and walk to the front and side of the Snowmobile or ATV until the strap is fully extended and tight. Use one or both hands. Stand off to the side at a slight angle. Pull on the strap handle using your body weight and keeping your back straight. At the same time have the driver slowly accelerate. You need only to exert just enough force when pulling to move the vehicle forward. As the Snowmobile / ATV begins to move forward and slack occurs in the strap, the hook will drop away provided you have followed the placement instructions above.

Some application may require two EZ-Out Pull Straps to be used – one on each side.



LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. **POWERMADD** shall not be liable for damage or injury caused by defective materials or workmanship. **POWERMADD** may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.