

# POWERMADD<sup>®</sup> Ski-Doo Blackout Loop

## Installation Instructions for Part No. 15897

### TOOLS REQUIRED:

- Pliers
- Wire Snips
- Jig Saw (Precision ski only)
- Scissors (Precision ski only)

### HARDWARE INCLUDED:

Qty	Description
1	Blackout Loop
5	Black Cable Ties


POWERMADD's Ski-Doo Blackout Loop was designed to mount in Ski-Doo's Plastic single runner ski. If you are installing the Blackout Loop on Precision ski, Ski-Doo's dual runner ski, follow the instructions below.

**Step 1:** Using a scissors, cut out the template below and tape to the Blackout Loop.

**Step 2:** Using a jig saw, cut off the lower section of the Blackout Loop.

**Step 3:** Use the edge of a utility knife to deburr the loop.

**NOTE:** Using chrome or glossy stickers on the Blackout Loop may cause problems with the staging lights.



SCALE : 1.000 TYPE : PART NAME : PR0097\_TEMPLATE SIZE : A

### LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

**POWERMADD<sup>®</sup>**

1-800-435-6881

[www.powermadd.com](http://www.powermadd.com)

PP5010 REV A