POWERMADD® Pro-Ride Windshields

Installation Instructions for Part No. 11821, 11830 & 11840

Needle Nose Pliers

HARDWARE INCLUDED: TOOLS REQUIRED:

HARDWAKE INCLUDED.		TOOLS KEQUIKED
Qty	<u>Description</u>	<u>Description</u>
1	Windshield	Drill
8	Well Nuts	3/8 Drill Bit
8	Snap Cap Washers	Phillips Screwdriver
8	Black Snap Caps	Standard Screwdriver

STEP 1: Start by removing the stock windshield. Use a needle nose pliers or standard screwdriver to remove the push pins holding the

windshield on.

8

Screws

STEP 2: Once the windshield is removed insert six of the well nuts into the holes in the pod. **Note:** You might need to enlarge the holes with the 3/8 drill bit if the well nuts do not fit. *Photo 1*

STEP 3: Set the new windshield in place and install the six screws. You do not need to install the bezel/trim at this time. *Photo* 2



Photo 1

Skip Steps 4-7 if you purchased the 11821

Continued on next page...



Photo 2

STEP 4: Once the windshield is secure, mark the location of the two rear mounting holes with the tip of your screwdriver. *Photo 3*

STEP 5: Remove the six screws and then the windshield.

STEP 6: Use the 3/8 drill bit to drill the holes in the location marked in step 4. Note: Use caution when drilling as to not drill too deep. *Photo 4*



Photo 3

STEP 7: Insert the last two well nuts into the holes you just drilled.

STEP 8: Set the windshield bezel into place.

STEP 9: Insert all screws with snap cap washers through the windshield and bezel into the well nuts. Once inserted, tighten the screws. Apply pressure to the windshield so the well nuts do not spin while tightening screws.

STEP 10: Install the black snap caps.



Photo 4

LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. **POWERMADD** shall not be liable for damage or injury caused by defective materials or workmanship. **POWERMADD** may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.