





# Handguard Gauntlet

Part # 34258

## Installation Instructions



**For use on PowerMadd Star Series, TrailStar and Sentinel handguards.**




|        |  |  |
|--------|--|--|
| Step 1 | Determine the correct side by making sure the PowerMadd logo faces up in the front. Open the Gauntlet and turn it inside out.                                |  |
| Step 2 | Slide the Gauntlet onto the handguard so that the two elastic straps go over the guard.  |  A close-up photograph showing the black gauntlet being slid onto the grey handguard. The two red elastic straps are visible, stretched over the top of the handguard. |
| Step 3 | Continue sliding the Gauntlet onto the guard until the straps are about halfway across the guard.  |  A close-up photograph showing the gauntlet further advanced onto the handguard. The red elastic straps are now positioned halfway across the top of the handguard.   |
| Step 4 | In this position you should be able to insert the inside edge of the handguard into the pocket in the Gauntlet.  |  A close-up photograph showing the inside edge of the handguard being inserted into the pocket of the gauntlet. The red elastic straps are still visible.            |
| Step 5 | Keeping the inside edge in the pocket, slide the Gauntlet back towards the outer edge of the guard and reposition the straps on the outer edge of the guard. |  A close-up photograph showing the gauntlet fully positioned on the handguard. The red elastic straps are now repositioned on the outer edge of the handguard.       |

# Handguard Gauntlet

Part # 34258

## Installation Instructions



|        |  |  |
|--------|--|--|
| Step 6 | Pull the Gauntlet around the guard, turning the Gauntlet correct side out.       |    |
| Step 7 | Close the inside of the Gauntlet by using the Velcro straps.                     |   |
| Step 8 | Cinch the strap through the buckle to close the Gauntlet around your handlebars. |  |
| Step 9 | Repeat for other side.   |  |

**LIMITED WARRANTY** POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effective for one year from the original purchase date.