Handguard Mounting Tips For Honda Rincon ATV

Check your handguard model:

- For Star Series Handguards use ATV/Moto mount kit #34252.
- For **Sentinel Handguards** (pictured) use ATV/Moto mount kit #34452.

Use these instructions along with the instructions provided with the mount kit.

For this mount kit to work on the Rincon you will need to remove the spacer tab from the throttle block assembly. The Rincon has a tab that protrudes from the throttle assembly which spaces the brake perch an exact distance from the throttle. This is to speed up assembly at the factory and can be removed. To remove use a hack saw and make a shallow cut on the top tab make sure not to cut the handle bars. Use a standard screw driver to get under the spacer and break it off.



Right side bracket:

Move the brake perch over to the left just enough to make room for the handguard mounting bracket – about ½ inch. Mount the handguard mounting bracket between the throttle block and brake perch with bracket going over the top of the lever as shown in the photo.





Left side:

Move the brake perch over to the left up against the control pod. Mount the handguard mounting bracket next to the brake perch. The bracket can go either over the lever or underneath the lever as shown in the photo. Mount bracket next to the left mounting tab on the handguard. See photo for reference. Adjust guard, brake lever and throttle to your personal preference.



Handguard mounting:

The handguard can be mounted to the bracket in multiple positions from left to right using the spacers provided. This allows you to get the handguard in just the right spot to provide the best protection. A good location is when the outside end of the handguard matches up with the outside end of the grip - as shown in the photo. Follow the instructions provided with your mount kit to mount the handguard.

Adjust guards, brake lever, and throttle to your personal preference and tighten all fasteners.